



Application:	Insulated cables or similar soft materials	
Max:	Cable dia	8mm
	Speed	1000 m/min
Air	Quality	Dry / Filtered
	Pressure	5 bar

## **Maintenance & Operating Instructions**

### **Visual Inspection**

Ensure there is a full set of ceramic pins in the top and bottom halves.

Check that the unit has a spring fitted to the black hinge bar.

Ensure that the top half sits squarely on the bottom half and is not being forced out of alignment by the air pipes.

### **Physical Inspection**

Check that the airstream from the holes in the top and bottom halves seems adequate and shared equally across all the holes.

Check that the spring closes the airwipe after opening.

### **Setting**

Ensure that the cable path opening is set so that the bottom and top halves of the airwipe lightly touch the cable. This is done by using all three knurled screws. The top and bottom halves should run parallel.

### **Cleaning the Airways**

The air jets should be clean. Clean using a pin.

### **Replacement of Ceramics**

The ceramic pins may occasionally need replacing and can be supplied by Marldon. The pins are held in place by adhesive and the holder lightly swaged.

20<sup>th</sup> October 2014

Tel: +44 (0)870 907 0017 · Email: [sales@marldon.com](mailto:sales@marldon.com) · Website: [www.marldon.com](http://www.marldon.com)

